

# AP-Line Anti Shatter Film

## Placement instructions



### To install the safety film, you will need:

- Spray bottle
- Small quantity of washing up liquid
- Sharp scissors
- Sharp knife or blade
- Tape measure
- Squeegee or other flexible rubber
- Towel or cloth

### Prepare your window...

A clean window is vital to a successful installation! Take time to clean your glass thoroughly before beginning the fitting process.

### Putting on the film:

1. Measure your window and note down the measurements. Carefully unroll your film on a clean, flat surface, with the backing sheet facing upwards.
2. Using sharp scissors, cut the film to a size slightly larger than your window.
3. Next, remove the clear backing sheet. Make sure you remove the sheet in a slow but steady fashion to avoid damaging the film.
4. Having removed the backing sheet, use the spray bottle to cover the entire surface of the film with soapy water solution. This helps to prevent the film becoming tangled and sticking to itself.
5. Cover the entire surface of your window with the soapy water solution. The soapy water will allow the safety film to be maneuvered into place.
6. Pick up your film and apply it to your window. Because of the soap, you should be able to move the film to the right position.
7. Once in place, spray the entire surface of the film with water. This prevents friction between the squeegee and the film.
8. Use the squeegee or other flexible rubber to push out any water or bubbles to the edge of the window. Start at the top of the window and work methodically down the glass.
9. Use a sharp blade to carefully trim the excess film at the edges, using the window frame as a guide.
10. Once the excess film has been trimmed and removed, spray the film with the soapy water solution again, and repeat the squeegee process to clear out any remaining air and water from behind the film.
11. Finally use the towel or cloth to dry the window and frame, being careful not to lift the film at the edges or corners.

